

SHOP MANUAL **LLOYD 600**

Directions and Hints
for Maintenance and Repair
of LLOYD Vehicles equipped
with 600 c. c. engines



LLOYD MOTOREN WERKE GMBH BREMEN

Copyright by LLOYD MOTOREN WERKE GMBH., GERMANY

This manual, or parts thereof, may not be reproduced or translated without written permission of the LLOYD MOTOREN WERKE. LLOYD MOTOREN WERKE reserve to themselves all rights in accordance with the enactments of the copyright law.

INTRODUCTION

As the 400-Manual, that has proved of value in shop practice, the present Shop Manual for the LLOYD 600 is destined as a Reference Book to make repairman still better acquainted, with all technical instructions and most convenient repair procedures for the LLOYD 600. Furthermore, it shall serve the purpose of bringing more clearly out our instructions and advice given in our customers service educational programs and allow all automechanics newly entered in the automotive service field to find practical suggestion and advice in cases of doubt. The Manual is subdivided into 13 main groups. Each main group is divided into sub-groups, each of them being consecutively numbered so that supplementary sheets may be inserted without fear of prejudicing the underlying principle of the main parts of this Manual. The different main groups will come out successively after completion and will be furnished uncalled to the LLOYD Servicing Shops.

LLOYD MOTOREN WERKE GMBH BREMEN

Service Department

TABLE OF MAIN GROUPS

1. **D** Technical Data
2. **S** Shop Equipment
3. **E** Engine
4. **C** Clutch
5. **T** Transmission and Differential
6. **FE** Fuel and Exhaust Systems
7. **FA** Front Axle and Steering
8. **RA** Rear Axle
9. **B** Brakes, Wheels and Tyres
10. **F** Frame
11. **B** Body
12. **EI** Electrical System and Fittings
13. **L** Lubrication and Maintenance